


# NLP110 Series

## Cover accessory kit


- Mount-on cover
- Easy to install
- No additional screws needed
- Complies with UL and VDE safety standards \*
- Mounting bracket kit also available

The NLP110 series is available with a mount-on cover accessory kit to facilitate flexible customer installation. The mount-on cover installation is independent of the power supply mounting position thus offering various mounting options to the customer and comes complete with mounting and grounding screws plus an insulator. The cover is installed directly to the power supply PCB allowing the power supply to be mounted either on the NLP110 mounting bracket or on the customer's system chassis. The mounting bracket and cover kit are sold as separate items to retain their inherent flexibility. Details of the mounting bracket assembly kit are available on our website. The NLP110 mount-on cover is flexible, easy to install and is suitable for applications that require power supply installation options with minimum mechanical work for the system designer.



2 YEAR WARRANTY

### SNAP-ON COVER KIT



#### MODEL NUMBER: NLP110C

##### Materials

- 1 Cover
- 1 Insulator
- 4 Mounting screws #6-32 x 3/16 inch
- 1 Installation instructions

##### Assembly Notes

- 1 Before assembly, ensure unit was turned off for at least 10 minutes.
- 2 Ensure that the insulator is correctly fitted in the customer chassis under the PCB to maintain safety creepage and clearances.
- 3 Position the power supply onto the customer chassis aligning the PCB assembly mounting holes with the 4 stand-offs on the chassis. Orientation of PCB assembly relative to the chassis must be as shown in the drawing opposite.
- 4 Put the cover on the PCB with orientation as shown in the drawing opposite.
- 5 Secure both the cover and the power supply with 4 screws through the holes as shown on the drawing opposite.
- 6 'Earth'\* grounding can be:
  - (a) Through system chassis when system chassis connected to the 'earth'.
  - (b) Through power supply cover. Connect 'earth' to cover as shown on drawing opposite.
- 7 When a cover or other sheetmetal option is added, it is the user's responsibility to ensure that the requirements of the relevant safety agency, or agencies, are complied with.

\* When installed follow the 'installation instructions'.