

# Installation Procedure For Resistant Hoods

---

## Assembly steps:

1. Hold connector shell in the position shown on the picture. The holes of the shell have to be placed over the screws in the hood. Attention: Do not push the shell further into the hood to avoid damaging the detent latches in the hood.
2. Place the assembly key between the connector shell and the hood over the detent latch. Gently pry open the hood while pushing the connector down into the slot behind the detent latch. Remove the assembly key.
3. Verify that the shell is positioned behind the detent latch on one side of the hood. Place the assembly key between the opposite side of the connector shell and the hood over the detent latch. Gently pry open the hood while pushing the connector down into the slot behind the detent latch.
4. Remove the assembly key. Verify that the shell is placed in both slots behind the detent latches.

