

DESIGN SOFTWARE

Quartus Prime Pro Edition

| Туре | Description | | |
|---|--|--|------------------------------------|
| New Purchases | | | |
| Fixed subscription | Quartus Prime software fixed-node subscription supporting all devices on Windows platforms. Includes subscription software updates for one year | | Ordering code - SW-PE-QRTS-FIX |
| Floating subscription | Quartus Prime software floating-node subscription supporting all devices on Windows and Linux platforms on a network. Includes subscription software updates for one year. | | Ordering code - SW-PE-QRTS-FLT |
| Additional floating seat | Quartus Prime software additional floating-node seat for floating-subscription products for one year. | | Ordering code - SW-PE-FLT-ADD |
| Renewals | | | |
| Fixed-subscription renewal | Quartus Prime software per-seat renewal for a fixed-subscription license. | | Ordering code - SWR-PE-QRTS-FIX |
| Floating- subscription renewal | Quartus Prime software per-seat renewal for a floating-subscription license. | | Ordering code - SWR-PE-QRTS-FLT |
| Upgrade from Standard Edition to Pro Edition | | | |
| Upgrade Fixed Standard Edition to Pro Edition | Includes subscription software updates for the remaining Standard Edition license duration. | | |

| | Quartus Prime Pro and Standard software fixed-node subscription supporting all devices on Windows platforms. | Ordering code - SW-PE-FIX-UP |
|--|--|---|
| Upgrade Floating Standard Edition to Pro Edition | Includes subscription software updates for the remaining Standard Edition license duration. Quartus Prime software floating-node subscription supporting all devices on Windows and Linux platforms on a network. | Ordering code - SW-PE-FLT-UP |
| Upgrade Additional floating seat | Quartus Prime software additional floating-node seat for floating-subscription products subscription software updates for the remaining Standard Edition license duration. | Ordering code - SW-PE-FLT-UP- ADD |

Quartus Prime Standard Edition

| Туре | Description | | |
|-----------------------------------|--|--|--|
| New Purchases | | | |
| Fixed subscription | Quartus Prime software fixed-node subscription supporting all devices on Windows platforms. Includes subscription software updates for one year (1) | | Ordering code - SW-QUARTUS-SE- FIX |
| Floating subscription | Quartus Prime software floating-node subscription supporting all devices on Windows and Linux platforms on a network. Includes subscription software updates for one year. | | Ordering code - SW-QUARTUS-SE- FLT |
| Additional floating seat | Quartus Prime software additional floating- node seat for floating-subscription products for one year. | | Ordering code - SW-QUARTUS-SE- ADD |
| Renewals | | | |
| Fixed- subscription renewal | Quartus Prime software per-seat renewal for a fixed-subscription license (3). | | Ordering code - SWR-QUARTUS-SE- FIX ⁽³⁾ |
| | | | |

| Floating- subscription | Quartus Prime software per-seat renewal for a floating-subscription license (3). | |
|---------------------------|--|--|
| renewal | | Ordering code - SWR-QUARTUS-SE- FLT ⁽³⁾ |

Additional Development Tools

| Туре | Description | | | |
|--|--|--|--|--|
| ModelSim [®] | | | | |
| ModelSim- Altera Edition software | ModelSim*-Altera* Edition fixed-node or floating-node subscription on Windows and Linux platforms. The subscription includes software updates for one year. For more detailed information on the software, please visit the ModelSim-Altera software product page. | | Ordering code - SW-MODELSIM- AE | |
| ModelSim- Altera Edition software Renewal | ModelSim®-Altera® Edition fixed-node or floating-node subscription on Windows and Linux platforms. The subscription includes software updates for one year. For more detailed information on the software, please visit the ModelSim-Altera software product page. | | Ordering code - SWR-MODELSIM- AE | |
| Digital Signal Proc | Digital Signal Processing Development Tool | | | |
| Fixed/Floating subscription | DSP Builder design tool requires an active license to Quartus® Prime | | Ordering code - IPT-DSPBUILDER | |
| Renewal: Fixed/Floating subscription | DSP Builder design tool renewal requires an active license to Quartus® Prime | | Ordering code - IPTR-DSPBUILDER | |

Notes:

- 1. With version 8.0 and later, FIXEDPC no longer includes or supports USB dongles. Licenses are tied to an NIC or similar.
- 2. To order by phone:
 - In the United States and Canada

- Outside the United States or Canada, contact your local Altera sales representative or distributor.
- 3. Renewal products can only be purchased for subscription products who are on active maintenance or less than 30 days after expiration.
- 4. Quartus Prime renewal for subscription products must be applied within 90-days after expiration. If your suscription product is not visible in Self Service Licensing Center, please contact us.

