# **BeagleBone Battery**

From BEAGLE BOARD TOYS WIKI

#### **Contents**

- 1 Descriptions
- 2 Specifications
  - 2.1 Electrical Specifications
  - 2.2 Mechanical Specifications
- 3 Signal Usage
- 4 EEPROM
- 5 Distributors
- 6 Product Images
- 7 Documentations
  - 7.1 BeagleBone Battery Revision A

### **Descriptions**

The BeagleBone Battery Cape provides a portable power solution for BeagleBone boards. This cape provides 5V power supply to the BeagleBone using everyday AA battery cells. The Battery cape can be used with up to 4 battery cells, which boosts the BeagleBone working time even longer. The BeagleBone Battery cape is also equipped with a power button, power indicator LED, and EEPROM for muxing configuration.



#### **Specifications**

Followings are some specifications of the BeagleBone Battery Cape:

#### **Electrical Specifications**

Power	3.0V via battery cells	
Indicators	One Power LED	
Connectors	Two 46-position connectors	
	One 10-position connector	

### **Mechanical Specifications**


Size	3.55" x 3.40"
Layers	2
PCB Thickness	.062"
RoHS Compliant	Yes

## Signal Usage

The BeagleBone Battery Cape uses 8 signals including:

- VDD\_3V3EXP
- VDD 5V
- DGND
- PWR BUT
- GPIO1 16
- I2C2 SCL
- I2C2\_SDA
- AIN4

## **EEPROM**



EEPROM Suport	Yes
Board Name	BeagleBone Battery Cape
Version	00A0
Manufacturer	BeagleBoardToys
Part Number	BB-BONE-BATT-01
Pins Used	17

## **Distributors**

Distributor list will be posted soon.

## **Product Images**



BeagleBone Battery

### **Documentations**

#### **BeagleBone Battery Revision A**

Documentations coming soon.

Retrieved from "http://beagleboardtoys.com/wiki/index.php?title=BeagleBone Battery"

- This page was last modified on 16 May 2012, at 00:08.
- This page has been accessed 388 times.
- Content is available under GNU Free Documentation License 1.3 or later.